

Floorsafe Deck Tread fitting recommendations for wooden, masonry and concrete floors

Please note, the following is a recommendation only and should be used as a guide. As every surface and substrate differ, common sense should prevail when fitting. Mechanical and mastic fasteners are also only a recommendation, as many brands are available. Deck Treads are not pre drilled, this is up to the customer's requirements. Deck Tread can be cut to length on site using a metal disc drop saw.

Pre Clean:

Before fitting Deck Tread, ensure to pre clean the underside with Isopropyl Alcohol, Methylated Spirits or detergent to remove any release agents or contamination on shipping.

This ensures a good key for the adhesive.

Fasteners:

Stainless steel screw 8 gauge screws self counter sinking, concrete plugs
Gorilla Grip Turbo

Fitting instructions for concrete surface:

1. Starting at one end, pre drill 5mm holes every 500mm evenly along middle of top of Deck Tread including one approx. 15cm from each end. (optional)
2. Ensure surface is clean, dry and free of any foreign matter
3. Place Deck tread in desired position and mark either end
4. Mark through the holes using a permanent marker pen on to concrete surface
5. Drill 4mm holes in surface to 50mm depth
6. Clean drillings off surface and insert plugs
7. Turn over each deck tread and apply a zig zag line of Gorilla Grip Turbo along the underside
8. Turn the nosing over so the antislip side is uppermost and locate it back in the fitted position marks. Screw down firmly in place
9. Walk over the entire length of the deck tread or nosing to ensure mastic makes full contact with both surfaces
10. Clean up any residue mastic with mineral turpentine and rags

Fitting instructions for wooden surfaces

Pre drilling is not needed if Anzor self drilling and countersinking screws are used. (Note screws need to be every 250mm for 50mm Deck tread or 500mm for 100mm Deck Tread)

Fitting instructions for tile and waterproof stairs

Use extra adhesive, use of bricks or similar weights can be used on top of the Deck Tread till cured if screws cannot be used

Because the application of these products are out of our control, Floorsafe NZ (2008) Ltd cannot and will not except any liability for any injury or damage caused by using these products.