

FLOORSAFE ANTI-SLIP SYSTEM APPLICATION PROCEDURE FOR TERRAZZO & CONCRETE

Thank you for choosing our Floorsafe anti-slip system. Please read this direction sheet before commencing application.

Check the contents of this box. Should there be any shortage or damage please call us on 07-5422240.

This Floorsafe anti-slip system pack contains FIVE products.

Product No.1 (pink liquid) Product No.2 (green liquid) Product No.3 (blue liquid) & Product TC (orange liquid) and a Floorsafe Maintenance Cleaner (also blue liquid). The four (no.1, no.2, no.3 and TC) products used together will make your slippery floor anti-slip safe.

BEFORE YOU START:

Remove all items from the area to be treated and sweep up all loose debris.

Lay towelling or protected sheet down beside working area to stand equipment on.

Make sure you have everything ready before you start. Soft broom, squeegee, watering can, mop & bucket (or hose) with plenty of clean cold water.

During application avoid splashing or walking products onto other floor surfaces as staining may occur. **Never allow the products to dry out. Do not apply to hot surfaces.**

DIRECTIONS FOR APPLICATION:

USE ALL THE LIQUID PROVIDED IN EACH BOTTLE

- 1) Wet the area to be treated by using a wet mop or hose. Pour out product No.1 in a puddle. Using a soft broom spread the solution over the floor surface to completely wet the floor.
- 2) Whilst product No.1 is wet immediately and carefully pour out product TC in a puddle and very quickly brush the liquid over product No.1 Avoiding splashing walls or equipment. To make sure edges and corners finish up clean repeat brushing of the liquids in those areas.
- 3) Leave for 5 minutes then rinse products from floor with plenty of clean water.
- 4) Brush excess liquids down drain waste outlet or mop up leaving the floor damp/wet.
- 5) Ensure area is still wet with water only. Pour out product No.2 in a puddle and brush liquid over the damp/wet surface. Brush this product well into the surface.

This product will now start to create the anti-slip effect. The leave on time to produce the required anti-slip effect varies from surface to surface. Between 3 – 10 minutes is all that's required. Do not let the area dry out during treatment, spray with a little water if it appears to be drying. **DO NOT LEAVE PRODUCTS ON FOR LONGER THEN REQUIRED** as over treatment may cause difficulties in cleaning the floor after treatment. To judge this push your foot with weight into the solutions on the floor. As soon as you feel your foot gripping the anti-slip is completed and step 6 should be done as quickly as possible.

- 6) Pour out product No.3 and brush liquid over product No.2
- 7) Immediately rinse the floor with plenty of clean water. Brush as much of the liquid down the waste drain outlet.
- 8) Repeat step 7.
- 9) Mop over floor and skirtings with clean water once or twice and leave to dry.

SHOWER ALCOVES: If a build up of body fats & soaps exist a second application maybe needed. THE FLOOR IS NOW ANTI-SLIP SAFE AND READY FOR USE.

Depending on the colour and surface a slight dullness or a 'Bloom' maybe visible after the treatment has dried. This is quite normal and will disappear with on-going cleaning.

A specially formulated cleaning product is provided in the box. Using this cleaner to clean your floor will keep your floor clean & anti-slip safe. For further supplies please call us.

Because the application of these products are out of our control, Floorsafe NZ (2008) Ltd cannot and will not except any liability for any injury or damage caused by using these products.