

## **Floorsafe Tape Fitting Instruction**

- Clean surface thoroughly with either methylated spirits and rags or detergent and water, ensuring no grease or grime is on surface. Allow to dry completely
- Cut tapes to desired length and round off corners
- Lay tapes down in final location (do not remove backing yet) and mark around edges with chalk or builders' pencil
- For rough surfaces prime with Nuplex Neoprime inside marked area ensuring to roll up to edges (use medium nap roller 75mm for 100mm tape)
- Allow to dry for 1 to 10 minutes depending on temperature
- Once primer is dry peel off tape backing and lay down tapes
- Walk over entire tape surface to ensure complete adhesion

Please note common sense should be used in relation to installation of tape.

Rough concrete may require 2 coats of Neoprime.

High humidity days or wet conditions should be avoided to ensure tapes do not lift.